

## Instructions for Downloading and Extracting the Firmware update file.

### Nanocom Evolution Instructions

1. Select the relevant Firmware update file (latest BBS V1.\*\*\*) for Nanocom Evolution from the Restricted area
2. Download the file which will save as a zip file. This must be saved to a location on your hard drive.
3. Use Windows utility or any one of the many file utilities available on the internet such as Winzip or Winrar or IZARC (most are free) to extract the files to a new folder. All files in the ZIP file need to be extracted to this same folder.
4. Locate the new folder and then inside this folder are 2 sub folders
5. Open the folder named kernel manager and select the file named NanocomEvoKernalManager.exe (note your laptop/PC may not show the file extension of exe if you have Known File extensions hidden (but that's what the file is!) Highlight the file and then press enter to run the file.
6. Connect your Nanocom Evolution to the laptop/PC via the supplied mini USB cable.
7. You will now see on the setup program that it shows Device Connected.
8. If this is the first time you have run the Firmware updater click on the Read Instruction manual and take time to read the contents so you fully understand which unit you are working with and how to perform the upgrade.

NOTE. Failure to read the instructions and follow them can result in an inoperable unit which is not a design defect simply one created by the user. If the unit needs to come back for repair due to incorrect usage of the updater, this will be chargeable. This process has been tested and used many hundreds of times without issue so we KNOW that there is no issue with the software!

The second folder in the unzipped file is ONLY required for anyone with an early Nanocom Evolution with Firmware still on a version less than V1.02 and is not required under any other circumstances